

Assembly Tutorial






Thank you very much for your purchase and support

If you have any questions about our products Please contact us through the following ways


Email: aingin@foxmail.com



Trolley chassis







Take out 1 2 3 from the bag. "Motor" label.









① 8 × M3*30 Screws



28 × hexagonal nut



34 × Speed code



⑦ 4 ×Wheels






⊕ 8 ×t-type bracket




5 6×M3 * 30 copper pillar



6 8 × M3*8 Screws

























If you think the assembly of smart robot cars is complicated

If you have any questions during assembly or testing, please
Via aingin@foxmail.com





